


Sardauscan Tutorial



Hugo BENOIT-JANNIN

This user manual only deals with steps for calibrating and Scanning an object in 3D with the scanner Sardauscan, the design part of the scanner Will not be discussed in this tutorial. If you want to build your Sardauscan Please visit: <http://www.thingiverse.com/thing:702470> where everything is (Material to be purchased, program for the Arduino, design of printed parts). Sardauscan is a low-cost, open-source 3D scanner that can compete with With a very good "plug and play" scanner costing more and being closed to any Change.

The Sardauscan uses red light beams, which will be Detected by the webcam, the webcam records the deformation of the light beam And then translate it as an image on the software.

Provide a large space around the scanner to prevent the scanning from recording Shapes too close, causing noise and false scanning.

Summary

• Installing the software interface 3-8	
• Hardware Calibration 9-17	
• Camera Calibration 10	
• Calibration laser	11
• Calibration position	12
• Image Calibration laser	13
• Calibration matrix	14-16
• Scan and treatment	17-18
• Some scans	19-23

Installing the Interface Software

Go <https://github.com/Sardau/Sardauscan> to download Interface software.

Branch: master New pull request

New file Find file HTTPS <https://github.com/Sardau> Download ZIP

Sardau Update FirmWare.ino Latest commit e9cdc32 on 24 Aug 2015

FirmWare	Update FirmWare.ino	6 months ago
STL	adding genius holder	9 months ago
Sardauscan	fixing icon	9 months ago
.gitattributes	Sardauscan	a year ago
.gitignore	ressource / license and sample plugin comment	11 months ago
.tfignore	ressource / license and sample plugin comment	11 months ago
LICENSE	ressource / license and sample plugin comment	11 months ago
README.md	adding accelstepper download link	11 months ago
SardauscanV004.zip	V004 binary	11 months ago

README.md

Download the ZIP file, Once the zip folder is downloaded, move the file Zip in your documents (it will unzip automatically). But we still have to deziper Another file in Sardauscan-master

Nom	Modifié le	Type	Taille
FirmWare	09/02/2016 12:23	Dossier de fichiers	
firmware modif	11/02/2016 12:04	Dossier de fichiers	
Sardauscan	10/02/2016 10:12	Dossier de fichiers	
STL	09/02/2016 12:23	Dossier de fichiers	
.gitattributes	09/02/2016 12:23	Fichier GITATTRIB...	1 Ko
.gitignore	09/02/2016 12:23	Fichier GITIGNORE	1 Ko
.tfignore	09/02/2016 12:23	Fichier TFIGNORE	1 Ko
LICENSE	09/02/2016 12:25	Fichier	35 Ko
README.md	09/02/2016 12:25	Fichier MD	2 Ko
SardauscanV004.zip	09/02/2016 12:23	Dossier compressé	1 803 Ko

Ouvrir

Ouvrir dans une nouvelle fenêtre


Extraire tout...

7-Zip

CRC SHA

Analyser SardauscanV004.zip

Once the file has been extracted, you have another file on behalf of "SardauscanV004" that appeared, enter this folder and then run the executable.




So you have your software launched, you have to recognize the different elements Of the scanner, previously connected.



Click on the tray or lasers icon, a window will open.


Update, select the proposed USB port and click "ok".

If nothing is detected, do not hesitate to unplug / reconnect the Arduino card



For the camera to check even if the icon is blue indeed the software may have recognized the camera


Integrated if you are using a laptop. To remove the built-in camera right click On the icon and then "remove".



Then choose "Hercules HD Twist" then click on "ok"

You can normally use each laser and the

Clicking on the laser icon, and then activating each laser independently.



It is likely that the tray does not turn, check whether LEDs on the board

Electronics are on, if they are on, the tray is working, if not

Not the case, it is necessary to modify some parameters in the code Arduino.

In case of problem
Open the FirmWare folder

FirmWare	09/02/2016 12:23	Dossier de fichiers	
firmware modif	11/02/2016 12:04	Dossier de fichiers	
Sardauscan	10/02/2016 10:12	Dossier de fichiers	
SardauscanV004	09/02/2016 14:05	Dossier de fichiers	
STL	09/02/2016 12:23	Dossier de fichiers	
.gitattributes	09/02/2016 12:23	Fichier GITATTRIB...	1 Ko
.gitignore	09/02/2016 12:23	Fichier GITIGNORE	1 Ko
.tfignore	09/02/2016 12:23	Fichier TFIGNORE	1 Ko
LICENSE	09/02/2016 12:25	Fichier	35 Ko
README.md	09/02/2016 12:25	Fichier MD	2 Ko
SardauscanV004.zip	09/02/2016 12:23	Dossier compressé	1 803 Ko

Then open Firmware.ino

configuration.h	09/02/2016 12:23	C/C++ Header	1 Ko
FirmWare.ino	09/02/2016 12:23	Arduino file	5 Ko
README.TXT	09/02/2016 12:23	Document texte	1 Ko
SerialCommand.cpp	09/02/2016 12:23	C++ Source	6 Ko
SerialCommand.h	09/02/2016 12:23	C/C++ Header	5 Ko
Wiring.png	09/02/2016 12:23	Image PNG	70 Ko

All you have to do is change

"#define Halfstep 8

#define REVOLUTION_STEP 4072 "

By

"#define Halfstep 4

#define REVOLUTION_STEP 2048 "

```

FirmWare SerialCommand.cpp SerialCommand.h configuration.h
#ifndef CONFIGURATION_h
#define CONFIGURATION_h

#define FIRMWARE_VERSION "Sardauscan V0.1a"

#define SERIAL_BAUD 115200
//57600

// Motor definitions
#define motorPin1 2 // IN1 on the ULN2003 driver 1
#define motorPin2 3 // IN2 on the ULN2003 driver 1
#define motorPin3 4 // IN3 on the ULN2003 driver 1
#define motorPin4 5 // IN4 on the ULN2003 driver 1


//tips (from Mark Benson)
//If anyone else is having problems with a BYJ48 stepper not doing anything,
//change the HALFSTEP value to 4 & REVOLUTION_STEP to 2048
#define HALFSTEP 8
#define REVOLUTION_STEP 4072
#define STEP_BY_MINMOVE 4 // move by STEP_BY_MINMOVE (to avoid power loss when position is between step)

#define LASER_COUNT 4
#define LASER_PIN_1 A1 //yellow
#define LASER_PIN_2 A2 //orange
#define LASER_PIN_3 A3 //green
#define LASER_PIN_4 13 //blue

#endif
```

Then click on "upload" the
New program is in the
Arduino map

An error message may appear, in fact it may miss a library in your Arduino software. For this go on <https://github.com/adafruit/AccelStepper> and Download the folder, and rename the "AccelStepper", respecting the Lowercase / uppercase.
Back in Arduino software




Add the AccelStepper library, then upload the new program, the latter should then settle into your Arduino without worries.
Your interface is now ready for use, but now you have to calibrate the to scan.

Hardware calibration

We will now calibrate the scanner, this task is the longest and the most complicated, but it is necessary that the calibration is done with care to obtain a result of good quality, so be patient and accurate.

To calibrate I advise you to print in 3D a half-cone (cut in height) and make a groove in its height (in the direction of the lasers), make the color black, this which avoids the diffusion of light through the material, which can distort our accuracy.



You have previously found the center of your turntable if it is not the case, you have to try to determine it, you can help yourself with your half-cone and your lasers. Place your half cone on the board and pass a laser through its top, then turn the tray, if the laser still remains at its top, you have found the center of the tray (mark its center for the next uses of the scanner).

Calibration camera

To calibrate the camera nothing more simple, go to the camera tab, then
In the "Physical calibration" section



Physical Calibration



Build Dimention



Correction matrix

Simply click on the bar
Horizontal and place it on the
Center of your tray, so your
Camera will be calibrated for scans
Future.

Calibration lasers

Laser calibration is one of the most complicated tasks to perform


By its precision. You will need to perform the operation for **each laser independently**. You need your half cone that you will place

Center of the tray, the flat side of the camera side.

Adjust the light beam to make it as thin as possible by turning the


Knob directly onto the laser. Then direct the light beam into the groove of the Half-cone (the groove is in the center of the tray). On your image you have to

The screen you do not have to distinguish the laser behind the green bar (see below).



Calibration Position

If you have not already done so, you have to calibrate the dimensions of your scanner, that is to say Positions of your camera and your different lasers, for that go in Tab "calibrate", then in "build calibrate" and enter the coordinates of the camera.



Tip: Do not switch the angle of the laser in accordance with the sign, contact information Will adjust themselves. Check all laser angles that can move by adjusting The other lasers.

Tip: print a circular protractor that you'll stick on the shelf

Calibration of the laser image

We will now adjust the image of the laser, ie eliminate possible noise

That the camera records. To do this, go to the "tune" icon and set for the parameters

So as to have a continuous line, and eliminate all isolated points.

The setting is different for each piece of scanned material (material reflection, color), it is essential to do so with THE piece you want to scan.



Threshold

Min Width

Max Width

Laser



Test Settings



Correction of matrix

Matrix Correction is the final step in calibrating the scanner and the Important. To do this take a piece with a particular shape, a tube with a bar Crossing it in its radius see next photo



Your calibration object must have a simple but irregular shape (eg no Single tube).

Now go to the tab "calibrate" then in "correction matrix"



Physical Calibration



Build Dimention




Correction matrix


Each setting is specific to your Environment, it's up to you to find it
A continuous line without an isolated point.

Place your calibration object in the center of the tray, then launch a quick scan. You will get shapes in your window (top view) so you just have to align your scans of different colors to make one.

Tip: Go see the "Process" tab and look what color scan respects. Scale the scanned object, do not touch the scan respecting the scale and align the others. Yes, the scans are not to scale but are aligned, a processing function allows to correct this error.




Here the green respects the dimensions, so we must align the red scanner on the green. Before any manipulation click on "clear this scan" and do it for each scan. Note in "process" that the scan



Red is more "lean" than the green scan, And the green scan is on a good scale, it must therefore align with the green scan.


Your scan is now calibrated, we will be able to scan
Treatment to eliminate noise and smooth scans.




Scanning and processing

Since the calibration of the scanner is done we can now do our first scans.

Go to the "process" tab and then drag the scan icon in the "drag task here" window.



A treatment list will appear on the left side of window, where each icon has a specific function.



Represents the filter icon and transformation



Represents the dot smoothing icon



Represents the icon of build



Represents the color icon



Represents the backup icon



Represents the parameter icon

The detail of each function is described below.

Filter:

Filter IQR: Removes scan errors with an IQR filter (standard filter in samples Of probabilities).

Filter Median: Removes scan errors with a "Median filter" (standard filter in The imagery).

Transformation:

Scale: Changes the scale to (x, y, z).

Smoothing:

Angle: Makes an average approximation of all scanlines based on an angle.

Laser: Makes an average approximation of all scanlines based on an angle.

Bézier: Makes an approximation of Bézier on each of the scanlines.

Surface: Makes surface smoothing with a simplified Laplace.

Color:

Texture Adjust: Adjusts the brightness, contrast and gamma of the texture.

Backup:

Load Sar: Opens a ".sar" file.

Save xxx: Save a file xxx. (Xxx, is for ply, xyz, ect).

The .ply and .xyz files are there if you prefer to use a

Surface reconstruction as "Meshlab" or other.

The .stl and .obj files are there for slicers (.obj files can be imported

In 3D modelers like "3ds Max" or "Blender".

Tip: It is advisable to make the raw scan and save it for later only

Work on scatter cloud processing. You must therefore drag the scan icon

The icon "IO: save.sar" in the right window.

Then import your .sar file into the software to apply the processing

Some scans

Here are some examples of scans with different objects and treatments
I use only two lasers for the moment, which are placed in position 1 and 2, are the positions closest to the camera.

Scans are very sensitive to the external environment and therefore to the parameters

We must apply to have a correct rendering. So I advise you to be in a room

Not too bright and not to put the scan in direct light and under a lamp, indeed

Too much luminosity decreases the precision of the laser and the outside light can vary and therefore


Change the quality of the scan.

Objects that fit on "legs" or "legs" are not ideal for scanning

Since the ground will then be scanned and can be misinterpreted when processing the objects.

Shiny objects are also not recommended because the material diffuses the laser and

Camera does not capture deformation.





Here it is noted that the dragonnet which is itself printed as a printer material

3D lack of details at the back, hands and tail is missing. We notice

Of pikes above his skull because the scan did not take the points of the skull (no Visible) and connected directly with spurious points.

For the camera on Notes that it lacks Of detail, this is due to the shape Of the object, in fact when the Turns the lasers Change or little position On the face of the object. And so we Does not take into account all of The object.










The tortoise is found in the case of the dragon with the top which is not scanned and
 Whose treatment links the points of the carapace with parasites. For the head one finds himself
 In a particular case where the lasers are too inconsistent with the camera and therefore
 Scan not the shape of the head well.



Balloon inflator is a rich object. In particular at the level of the grid. Thermal evacuation of the object, which did not. Could be scanned correctly, due to the. Large size of the object, the top of the object. Is not scanned.





The Hello Kitty remains an ideal object for this scanner one notices that the details are of Good quality, however here a sudden drop in brightness (a cloud The sun) modified some points of the scan (white lines on the side of the balloon) and thus Rendering the scanner rendered.

